

adattatore M12 fem. x-code / RJ45 mas. 0°

Adattatore
M12 – RJ45
Femmina diritto – femmina diritto
8 poli
X-code
Gigabit
Ethernet CAT6A
schermato
Ghiera metallica




[Link al prodotto](#)**Immagine**

Immagine rappresentativa



| | |
|--------------------------|-----|
| Family construction form | M12 |
| Codifica | X |

dati commerciali

| | |
|------------|----------|
| ECLASS-6.0 | 27143423 |
| ECLASS-6.1 | 27279221 |
| ECLASS-7.0 | 27440104 |
| ECLASS-8.0 | 27440104 |

| | |
|----------------------------|---------------|
| ECLASS-9.0 | 27440106 |
| ECLASS-10.1 | 27440106 |
| ECLASS-11.1 | 27440106 |
| ECLASS-12.0 | 27440106 |
| ETIM-5.0 | EC002640 |
| GTIN | 4048879699402 |
| Lotto minimo ordinabile | 1 |
| Numero di tariffa doganale | 85366990 |

Dati elettrici | Alimentazione

| | |
|---------------------------|--------|
| Corrente di esercizio max | 1,75 A |
|---------------------------|--------|

Dati tecnici | Comunicazione industriale

| | |
|---------------------------|----------|
| Protocollo supportato | Ethernet |
| Parametri di trasmissione | CAT6A |

Installazione | Collegamento

| | |
|-----------------------|------|
| Apertura della chiave | SW18 |
|-----------------------|------|

Important installation notes

| | |
|------------------------|---|
| Note on strain relief | Protect the connectors by suitable measures from mechanical loads, e.g. by the usage of cable ties. |
| Note on bending radius | Attention: Observe the permissible bending radii when laying cables, as the IP protection class can be endangered by excessive bending forces. |